

acoustic panel installation

corner traps





required tools



- 1. pencil
- 2. marker
- 3. tape measure
- 4. 1/8" drill bit
- 5. 1/2" drill bit
- 6. drill
- 7. flat head screwdriver
- 8. pliers/wire cutters



hardware (per panel)



eye screws (x2)



s hooks (x2)




hook screws (x2)





turnbuckles (x2)





chain (x2)





toggle bolts 3/16"x 3" (x2)



step 1 – panel placement


- A. layout where the panels will go in your room
- B. determine hardware location (on panels and walls)
- C. corner traps stacked on the floor can be installed with one hardware set.
- D. panels straddling a wall ceiling/corner or installed up off of the floor should be installed with hardware at both ends of the panel.








step 2 - mark the wall



E. after determining the panel and hardware placement, mark the locations where you will drill pilot holes

step 3 – check for studs

- F. check the hardware location marked in step 2 for the presence of a stud
- G. drill a small test hole or use a stud finder to confirm whether there is a stud behind the wall.





step 4 – wall hardware


H. if studs are present, proceed with the #6 screw hooks



I. if studs are not present, proceed with the toggle/eye bolt combo



step 5 - drill pilot holes




- J. stud installation
- 1/8" pilot hole for screw hooks into a stud

K. drywall installation

- 1/2" pilot hole for toggle bolts



step 6 – secure wall hardware




- L. stud installation
- screw hook screw into pre
 dilled hole(s)

*the flat screwdriver can be used here to tighten the screw


M. drywall installation

 push toggle bolt through predrilled hole(s) *ensure the wings have fully opened on back side of wall







step 6 – secure eye screws to acoustic panel



N. on the back of the panel find the center point and mark it

O. drill 1/8" pilot hole for eye screw






P. screw in eye screw(s)





step 7 – installing the corner trap



Q. attach chain to screw hook or toggle bolt (if using the toggle bolt configuration a s hook will be required)

R. using the hook side of your turnbuckle, attach it to the chain (extend turnbuckle prior to attaching so it can be tightened later)






S. bring the acoustic panel into position and attach the s hook to the eye screw



step 7 – installing the corner trap cont.



T. rotate the turnbuckle to tighten it, pulling the acoustic panel securely into the corner

step 8 - you're all done

RECORD MIX PRODUCE!





ACOUSTICS SIMPLIFIED

